

Diagnostic History

The Report is created by **LAUNCH X-431**

Vehicle Information

License #:

Year:2013

Make:Land Rover

Model:Discovery 3\4(L319)

VIN: [REDACTED]

Odometer:198202 km

Test Time:2024-08-02 10:30:49AM

Vehicle Software Version:V33.88

Diagnostic Application Version:V7.05.026

User Operation:Automatically Search
Automatically Search > Health Report

DTC

DTC	Description	State	System
P00BD-07	Mass or volume air flow A circuit range/performance - Air flow too high	Historic	ECM (Engine Control Module)
P0033-00	Turbocharger/supercharger bypass valve control - circuit open.	Intermittent	ECM (Engine Control Module)
P0658-00	Actuator supply voltage A - circuit low	Intermittent	ECM (Engine Control Module)
P1247-00	Turbocharger boost pressure low	Historic	ECM (Engine Control Module)
P0235-94	Turbocharger/supercharger boost sensor A circuit	Historic	ECM (Engine Control Module)
P169F-00	Control module - Unused fault code	Historic	ECM (Engine Control Module)
P250A-92	Engine oil level sensor - circuit	Historic	ECM (Engine Control Module)
P250A-37	Engine oil level sensor - circuit	Intermittent	ECM (Engine Control Module)
P250A-38	Engine oil level sensor - circuit	Intermittent	ECM (Engine Control Module)
P0195-00	Engine oil temperature sensor circuit	Historic	ECM (Engine Control Module)
U0415-68	Invalid data received from ABS control module	Intermittent	ECM (Engine Control Module)
P0676-00	Cylinder 6 glow plug - circuit open.	Permanent	ECM (Engine Control Module)
U0167-00	Lost communication with vehicle immobiliser control module	Intermittent	ECM (Engine Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	ECM (Engine Control Module)
P215B-62	Vehicle speed/output shaft speed correlation	Intermittent	TCM (Transmission Control Module)
P0850-29	Park/neutral switch input circuit	Intermittent	TCM (Transmission Control Module)
U101B-87	Lost communication with GSM - multiple bus	Intermittent	TCM (Transmission Control Module)
P1707-72	Transfer case neutral or park/neutral indication circuit.	Permanent	TCM (Transmission Control Module)
U0128-63	Lost communication with parking brake control module	Permanent	TCM (Transmission Control Module)
P279D-64	Four wheel drive range signal circuit	Intermittent	TCM (Transmission Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	ABS (Anti-lock Braking System)
U0300-00	Internal control module software incompatibility	Intermittent	ABS (Anti-lock Braking System)
U0421-68	Invalid data received from ride level control module	Permanent	ABS (Anti-lock Braking System)
U2300-54	Central configuration	Intermittent	ABS (Anti-lock Braking System)

B1A00-16	Control module	Intermittent	SRS (Supplemental Inflatable Restraint System)
B100D-64	Column lock authorisation	Historic	IPC (Instrument Cluster Control Module)
U0102-00	Lost communication with transfer case control module	Historic	IPC (Instrument Cluster Control Module)
U0121-00	Lost communication with ABS control module	Historic	IPC (Instrument Cluster Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	IPC (Instrument Cluster Control Module)
U0132-00	Lost communication with ride level control module	Intermittent	IPC (Instrument Cluster Control Module)
U0208-00	Lost communication with the seat control module A	Intermittent	IPC (Instrument Cluster Control Module)
U0242-00	Lost communication with the headlamp control module B	Historic	IPC (Instrument Cluster Control Module)
B102B-87	Passive key	Historic	BCM (Body Control Module)
B1B01-87	Key transponder	Intermittent	BCM (Body Control Module)
B1311-87	Clock module	Intermittent	BCM (Body Control Module)
B1C90-13	Auxillary driving lamps relay coil circuit	Permanent	BCM (Body Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	BCM (Body Control Module)
B134E-11	Switch illumination adjustment control	Intermittent	BCM (Body Control Module)
B10A2-31	Crash input	Historic	BCM (Body Control Module)
C1A71-1c	Rear right height sensor supply	Permanent	RLM (Ride Level Control Module)
C1A05-1c	Rear left height sensor	Permanent	RLM (Ride Level Control Module)
C1A06-1c	Rear right height sensor	Intermittent	RLM (Ride Level Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	RLM (Ride Level Control Module)
U0300-55	Internal control module software incompatibility	Intermittent	SASM (Steering Angle Sensor Module)
U0402-64	Invalid data received from transmission control module	Pending	GSM (Gear Shift Module)
U3003-16	Battery voltage	Historic	GSM (Gear Shift Module)
P0713-00	Transmission fluid temperature sensor A - circuit high input	Permanent	RDCM (Rear Differential Control Module)
P2743-00	Transmission fluid temperature sensor B - circuit high input	Permanent	RDCM (Rear Differential Control Module)
P0807-00	Clutch position sensor - circuit low	Permanent	RDCM (Rear Differential Control Module)
P186A-00	Differential lock-up actuator brake control - circuit/open	Permanent	RDCM (Rear Differential Control Module)

P0900-00	Clutch actuator - circuit/open	Permanent	RDCM (Rear Differential Control Module)
U0300-00	Internal control module software incompatibility	Intermittent	RDCM (Rear Differential Control Module)
U0422-68	Invalid data received from the body control module	Intermittent	RDCM (Rear Differential Control Module)
P0562-00	System voltage low	Intermittent	TCCM (Transfer Case Control Module)
U0128-00	Lost communication with parking brake control module	Permanent	TCCM (Transfer Case Control Module)
U0300-00	Internal control module software incompatibility	Intermittent	TCCM (Transfer Case Control Module)
U3002-81	Vehicle identification number	Intermittent	DSM (Driver's Seat Module)
U1A24-87	MOST ring complete, no communication	Intermittent	FCDIM (Front Control/display Interface Module(High Level Display Front))
U3003-62	Battery voltage	Intermittent	FCIM (Front Controls Interface Module(Heating Ventilation Air Conditioning Controls))
U3003-62	Battery voltage	Intermittent	FCIMB (Front Controls Interface Module B(Front Audio Control Panel))
B1286-16	Interior mirror	Intermittent	HCMB (Headlamp Control Module B)
B1081-00	Left temperature damper motor	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
B1082-00	Right temperature damper motor	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
B1085-00	Defrost damper motor	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
B1086-00	Air distribution damper motor	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
U0140-87	Lost communication with body control module	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
U0256-87	Lost communication with the front controls interface module.	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
U3000-87	Control module	Intermittent	HVAC (Heating Ventilation And Air Conditioning Control Module)
U201F-00	External receiver	Historic	RFA (Keyless Vehicle Module)
B1B57-11	Front sensors power circuit	Permanent	PAM (Parking Assist Control Module)
B1B58-11	Rear sensors power circuit	Permanent	PAM (Parking Assist Control Module)